


INSTRUCTIONS ORBISK



1. Present the food at the LED light



2. Wait for the beep



3. Done! Throw the food into the bin

CAREFUL!


Do not lean on the bin before, during or after taking a photo. It disturbs your registration.

Camera

LED light



 The Orbi is ready to take a photo: You're good to go!

 You're keeping the food too close to the camera. Present the food a bit lower, near the led strip.

 The Orbi is processing the picture and weight. Please do not hold anything in front of the camera.

